



MODEL NUMBERS:  
LF-2001-LED-10  
LF-2002-LED-10  
LF-2003-LED-10

# Ovalisk Light Fixture

## Owners Manual



LF-2001-LED-10 16" 32W LED 4000K DIMMABLE

LF-2002-LED-10 14" 26W LED 4000K DIMMABLE

LF-2002-LED-10 10" 16W LED 3000K DIMMABLE

Please consult your electrician for hanging fixture and wiring.



**WARNING:**

To avoid electrical shock turn off power at the fuse or breaker box.



**WARNING:**

Wires need to be connected to driver found in canopy and should NOT be connected to power source or a short may occur




Turn off the main power at the circuit breaker before installing or servicing the light fixture to prevent possible injury from electric shock.



Make sure that all wiring conforms to local and local electrical code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections, obtain services of a qualified electrician. Use wire nuts to cap all connections.

**Plastic electrical tape is not recommended.**



### INSTALLATION INSTRUCTIONS:

1. Pull the supply wires and house ground wire from the outlet box.
2. Thread the fixture screws into the appropriate threaded holes of the outlet box.

### ELECTRICAL CONNECTIONS:

3. Connect the fixture's black wire to the black wire in the supply box and the fixture's white wire into the white wire in the supply box using a wire nut.
4. Connect the fixture's ground wire to the ground wire in the supply box using a wire nut. Wrap all connections with electrical tape to ensure a secure connection.
5. Carefully tuck all wires back into the outlet box. Place fixture pan over outlet box and feed fixture screws through keyhole slots. Rotate the fixture pan clockwise until screws slid into the narrow end of keyhole slots and tighten firmly.

### FINAL ASSEMBLY:

6. Secure the lens and ring to fixture pan using three cap nuts.
7. Restore power at the circuit breaker and turn light switch to activate the fixture.



For more information, visit us at [www.wagonway.com](http://www.wagonway.com)